

16v Clock and heater bulb replacement

Digital clock bulb is easy. All you need do is unclip the panel holding the clock and switches.

Slide a thin blade top and bottom and release 2 snaps above and below the Fog lamp and Heated Rear Window switches. It will then lift out so you can then get at the back of the clock.

To continue with the heater control, pull out the three rotary dials on the heater control and you'll see two tiny Philips screws on the side ones.

Undo them and undo the two normal sized Philips screws that are at the top of this panel (just covered by the clock & switches panel)

Note; the clock bulb is identical to the dash bulbs.

Take care not to break anything!